

MIRACLE NAIL DUST COLLECTOR







1. Part introduction



< Types of filter >

after checking the advantages and disadvantages of each type, choose and use only one that is preferred

5 5	71 7
HEPA filter	Disposable filter
Advantages	Advantages
* Can be used multiple times after first installation and is more convenient than disposable filters	* The dust collector performs at 100% suction efficiency on every use
* Causes less dust in the air and easier to move when the dust collecter needs to be moved after using	* A clean filter is used every time, making it a hygenic option
* Can take more uses,making it an economical option	
Disadvantages	Disadvantages
* Difficult for the dust collector to reach 100% suction efficiency because there is always some dust remaining even after cleaning	* Less convenient and more expensive than multi- 1use filters because it has to be replaced for every use
* When cleaning the dust (bin), the dust may blow away causing secondary health risk (please wear a safety mask when cleaning)	* After using the dust collector, moving it or having a gentle breeze around it can cause airborne dust, so the dust must be disposed as soon as possible
* Washing the filter with water more than once significantly reduces the effectiveness of the filter, so washing the filter is not recommended	as soon as possible




Dust collector

2. Product Manual













1. Connect the dust collector to a power source.

- 1 First, plug the power plug into an outlet.
- 2 Plug the adapter connector into the power supply of the dust collector.

2. Choose a preferred filter.

When using a HEPA filter

- ① Check the direction of the arrow on the side of the HEPA filter and insert it into the main body of the dust collector in the same direction (Make sure to insert them in the same direction. There is a front and back distinction.)
- 2 Place the grate over the filter and secure it in place.

When using a disposable filter

- (1) First, place the grate on top of the main body of the dust collector.
- ② Place the disposable filter over the grate and adjust the position so that there is no visible gap.



3. Turning on the power

- Turn the switch knob on the side to turn on the power and set the desired speed and noise level.
- * When using a disposable filter, it can be adjusted more easily by adjusting the filter while the power is slightly turned on.

4. Status indicator

- Wired & wireless: Express the speed in 5 colors for 5 steps.
- Wireless: Display battery remaining capacity in 3 steps

5. Use

- Take a refreshing care of your nails with the Nail Dust Collector.
- Using a USB lamp allows a brighter work environment.
- You can turn it on / off with the switch on the other side of the lamp.

Warranty Certificate

- The warranty period for this product is 1 year.
- SAEYANG warrants its product in accordance with the Fair Trade Commission notice on the consumer dispute resolution standards per item category.
- Parts retention period: 3 years after product discontinuation

Free Service

Consumer Damage Types				Compensation	
				Within Warranty Period	After Warranty Period
In case of malfunction or loss in performance under normal use within the parts retention period	When a major repair is needed within 10 days of purchase			Exchange or full refund	
	When a major repair is needed within 1 month of purchase			Exchange or free repair	
	Damages incurred during transportation at the time of purchase or during product installation			Product exchange	N/A
	Damage incurred within 1 month of product exchange requiring a major repair			Full refund	
	When product exchange is		the same defect for up to 4 times	Free repair	Paid repair
	Repairable	In case of malfunction due to	the same defect for up to 5 times	Exchange or full refund	Paid repair
			different defects for the 5 time	Exchange or free repair	Paid repair
	In the event the service provider loses the product requested by the consumer for repair			Product exchange	Refund less depreciation
	In the event a repair is not possible because the repair parts were not retained for the parts retention period				
	In the event repair parts are available but a repair is not possible nonetheless				
In case of malfunction due to the fault of the consumer	In the event repair is not possible			Exchange after an amount corresponding to a paid repair has been received	Exchange less depreciation after paid repair amount has been received
	In the event repair is possible			Paid repair	Paid repair

Paid Service

- In the following cases, a fee will be charged when applying for service even during the free service period.
- In the event the product breaks due to the fault of the consumer
 - · In case of product damage or malfunction caused by dropping the product or an external impact
 - In case of malfunction due to negligence, not using a filter, or using with wet products (wet tissues, towels, etc.)
 allowing water into the interior of the product by the consumer
 - · In case of malfunction caused by using third-party consumables and accessories not specified by SAEYANG
 - In case of malfunction due to the repairing or altering of the product by a service provider or agent not authorized by SAEYANG
 - · In case of malfunction caused by not using the normal electric capacity
 - In the event the malfunction is caused by an external cause and not by a defect in the product itself, such as the work of a power breaker or a faulty power outlet
 - ** The description of the product malfunction, the customer's name, contact information, and address must be separately noted, and the power adapter must be enclosed with the product when sending.
 - ** The package contents of the product other than the main body are consumables, so please purchase them once they are consumed.
- * Refunds must be made at the place of purchase.

Manufacturer

MRC

273, Hannuri-daero, Sejong-si, Republic of Korea hunnyjoa@gumiho.co.kr

Distributor SAEYANG CO..LTD

348, Seongseo-ro, Dalseo-gu, Daegu, Republic of Korea www.saeyang.com

marathon@saeyang.com